



## AI-60xx Multi-Channel Control Module User Guide

(V9.3)



### Precautions for Use

1. The user of this product must have sufficient knowledge of electrical systems and ensure that this product is not used in situations that may pose a danger to personal safety or property.
2. The content of this manual is for reference only. Due to differences in product models and versions, some models or versions may only have partial functionality as described in this manual, and some features may not be covered here. For any questions, please contact the company's technical support hotline at 4008882776.
3. Before using this product for the first time, please read the entire user manual carefully to ensure proper use.
4. The company's responsibility is limited to the product itself, and it is not liable for any other direct or indirect losses or liabilities.

### 1. Model Definition

The AI-6016D92 represents a 16-channel NPN output  
The AI-6032D92 represents a 32-channel NPN output

### 2. Technical Specifications

#### ● Communication Method:

Bottom RS485 bus terminal; Support MODBUS-RTU protocol; Baud rate adjustable from 4800~115200.

The bottom RS485 bus terminal can connect to the company's TCP-MODBUS and EtherCAT communication controllers, supporting related communication protocols.

Internal dedicated communication protocol is adopted between the host, slave, and expansion modules, with a reliable communication distance of 30m.

Communication delay: the communication delay of each input or output expansion module node is approximately 10mS (including data transmission time) when connected in series.

#### ● Input Specifications:

Refer to the relevant extended input module for technical specifications.

- **Control Cycle:** Minimum 20mS (single-loop control); for multiple loops, each loop occupies 10mS.

#### ● Control mode:

ON/OFF control mode(adjustable hysteresis)

AI artificial intelligence control, incorporating advanced control algorithms with fuzzy logic PID regulation and parameter auto-tuning capability, as well as a manual control mode

#### ● Input specifications:

NPN switch output: Maximum voltage 28V , maximum current 100mA.

When driving relay coils, a fast recovery diode must be connected in parallel with the coil to absorb reverse voltage

When using external expansion output modules, refer to the relevant module user manual for technical specifications

- **Alarm Functions:** High limit, low limit, deviation high limit, deviation low limit, and other methods

- **Electromagnetic Compatibility:** IEC61000-4-4 (Electrical Fast Transient) ±6KV/5KHz, IEC61000-4-5 (Surge) 6KV, and the instrument operates without freezing or malfunctioning of I/O ports under 10V/m high-frequency electromagnetic interference, with measurement value fluctuation not exceeding ±5% of the full scale

- **Isolation Withstand Voltage:** Between power supply, relay contacts, and signal terminals ≥ 2300V; between isolated low-voltage signal terminals ≥600V

- **Power Supply:** 24VDC, -15%, +10%

- **Power Consumption:** ≤0.3W (when there is no output or external power feeding consumption); total maximum power consumption of the entire unit ≤3W


- **Operating Environment:** Temperature -10~60℃ ; Humidity ≤90%RH

### 2. Display Panel and Keyboard Operation Instructions

#### 2.1 Panel Description

The instrument can be connected to an E85 handheld device, which allows for display panel and keyboard operation. This enables quick viewing and modification of parameters using the Yudian control panel-style interface. It also allows for convenient operation in case the host computer is malfunctioning or unavailable.

Upon powering on the instrument, it will automatically cycle through the measurement values of each channel. By pressing the up and down buttons, users can quickly switch between channels and lock the display to show the measurement value of a specific channel. Pressing the circle button will exit the lock and restore the automatic cycling display of measurement values.




- ① Upper Display Window: Display measured values PV, parameter names, etc.
- ② Lower display window: Display the set value SV, alarm code, parameter values, etc.
- ③ 10 LED indicators, currently undefined for this module
- ④ Set Key (also used for toggling between manual/automatic cycle display)
- ⑤ Data Decrease Key (Also used to switch to the previous channel display)
- ⑥ Data Shift (Also used to switch to setpoint display)
- ⑦ Data Increase Key (Also used to switch to the next channel display)
- ⑧ 1394 socket and wiring

Note: The 1394 socket and wiring of this module are designed specifically for interconnection between our company's products. Do not use it to connect to other 1394 devices, as this could potentially damage the product.


#### 2.2 Global and Group Parameter Settings

Long press the Set key to enter the group parameter and global parameter setting mode. The module will first display the shortcut parameters defined by the EP parameter. While on the first shortcut parameter screen (e.g., Addr), long press the Set key again to display the LOC parameter. After unlocking, the 4 preset input/output configuration parameters and global function parameters can be displayed and configured. In the parameter setting mode, long pressing the Shift Key will return to the previous parameter. If the Set Key is pressed simultaneously, the user can exit the parameter setting mode immediately.



#### 2.3 Channel Parameter Settings

Long pressing the Shift Key will enter the parameter setting mode for the currently displayed channel. Users can view and modify setpoint values and PID parameters, etc. If the parameter lock Loc is unlocked, the values can be modified. In the parameter setting mode, long pressing the Shift Key will return to the previous parameter. If the Set Key is pressed simultaneously, the user can exit the parameter setting mode immediately.



### 3. Communication Protocol and Parameter Register Description

This instrument can be connected to the host computer via an RS485 serial port or through a Yudian TCP-Modbus or EtherCAT communication controller. This model uses an asynchronous serial communication interface, and the interface level complies with the RS485 standard. The data format consists of 1 start bit, 8 data bits, no parity bit or even parity bit, and 1 stop bit. The communication baud rate can be adjusted from 4,800 to 115,200 bps. If the baud rate exceeds 28,800 bps, an optional high-speed optocoupler communication module is required. For long communication distances, a baud rate of 4,800 bps is recommended.

The instrument can support 03H (read parameter and data), 06H (write single parameter) and 10H write multiple parameter commands under MODBUS-RTU protocol. It can communicate with other MODBUS devices. To ensure the communication speed, the AI instrument uses RTU (binary) mode. The communication interface settings allow for the selection of 1 to 2 stop bits, no parity or even parity, and instrument addresses in the range of 0~80.

For the 03H command, a maximum of 32 datas can be read at a time, with each data being 2 bytes. For example, to read 2 data, the command would be as follows:

Instrument address	Read command (function code)	Read parameter address code	Read data length	Check code
XXH	03H	00H 01H	00H 02H	CRC

For the 06H command, one data is written at a time. The command sent would be:

Instrument address	Write command (function code)	Write parameter address code	Write data value	Check code
XXH	06H	00H 01H	03H E8H	CRC

The format for the 10H write command allows a maximum of 16 data (32 bytes) to be written at a time. For example, the command to write a single data would be:

Instrument address	Write command (function code)	Write parameter address code	Write number of data	Write bytes	Write data value	Check code
XXH	10H	00H 01H	00H 01H	02H	03H E8H	CRC

The parameter types are divided into channel-independent parameters, configuration group parameters, and global parameters. The channel-independent parameters consist of 12×32 parameters. Each channel can independently define the following 12 parameters: setpoints, proportional band, integral time, derivative time, control mode, output value (including manual value write settings), control output parameter group number, and table pro-

gramming entry address, input channel and group assignment for setpoints and PID parameters, input specification groups, and input table correction entry addresses, input offset correction, high limit and low limit alarms. Configuration group parameters include 4 groups of input configuration parameters and 4 groups of control output configuration parameters (including alarm configurations). The measurement input group parameters include input specifications, filter intensity, scale lower limit, scale upper limit, and other parameters. The output group parameters include output limits, positive and negative deviation alarms, hysteresis, and functional configurations. Configuration group parameters are effective for the channels that select these parameters, and multiple channels can share one or more configuration groups. In addition, there are global parameters such as communication address and baud rate. Global parameters are applicable to all channels, and the parameter addresses are listed in the table below (Note: depending on the extension software, some products may not have all the parameters. In the document, "XX" represents the channel number).

#### This instrument only uses parameters related to the control section

Address Code	Register	Parameter Name	Functional Description
0000H~005FH	0000~0095	SP01~SP96 Group 1~96 Preset Set-points	Setting range: -9990~32000. The setpoint and PID together form a parameter group consisting of 4 parameters. Output channels can select different groups as setpoint and PID parameters via the PnXX parameter. Typically, the output channel number and PID parameter group number are the same, but the output channel can also switch to choose different setpoint and PID parameter groups. Different output channels can share the same PID and setpoint parameter groups.
0060H~00BFH	0096~0191	P 01~P 96 Proportional Band	Setting range: 0~32000, with the same unit as the setpoint.
00C0H~011FH	0192~0287	I 01~I 96 Integral Time	Unit: 0.1 seconds, setting range: 0.0~3200.0 seconds.
0120H~017FH	0288~0383	d 01~d96 Derivative Time	Unit: 0.01 seconds, setting range: -327.60~+327.60 seconds. (The maximum result for auto-tuning is +327.60. For larger values, you can manually write the value as an unsigned 16-bit number, which will be displayed as the corresponding signed 16-bit value on the table.)
0180H~01DFH	0384~0479	In01~In96 Input Channel Configuration Parameter Group Selection	Setting range 0~9999. The unit digit is set to 1~4 to select the input specification group for the configured measurement channel. Setting it to 0 disables measurement for that channel. The tens and hundreds digits configure the multi-segment curve correction address for the measurement channel. Setting it to 0 disables the correction. For example, setting In01~112 means that Channel 1 selects the 2nd input configuration parameter group, and the multi-segment curve correction entry address for that channel is d11.
			<div>Thousand digit</div> <div>Hundreds digit</div> <div>Tens digit</div> <div>Units digit</div> <div>0: Close the corresponding input measurement channel. 1~4: Select the corresponding input specification group. For example, setting In01=2 means that the input specification for channel 1 (CH01) corresponds to INP2, SCL2, SCH2, FIL2; 5~9: Spare</div>
			<div>Used for input nonlinear correction functions 0: Do not enable the multi-point nonlinear correction function 1~95: input channel multi-point correction entry address. For example, setting In01~11 means that channel 1 selects the first input specification group, enables the input nonlinear correction function, and the correction entry parameter is d1. If only one channel is enabled, a maximum of 97 correction points can be used. For detailed usage, refer to the section below.</div> <div>Reserved</div>
01E0H~023FH	0480~0575	Sc01~Sc96 Input Channel Measurement Value Offset	Setting range: -9990~32000, used for offsetting and correcting the measurement value. Specifically, if the input channel measurement is disabled, the physical measurement value will be 0. Writing this value is equivalent to assigning the measurement value for that channel via the host computer or program.
0240H~029FH	0576~0671	On01~On96 Output Channel Configuration Parameters Description	Setting range 0~9999. The unit digit is set to 1~4 to select the output channel configuration parameter group. The tens, hundreds, and thousands digits are reserved for future use. When the default value is 0, it is associated with output parameter group 1. <div>Thousand digit</div> <div>Hundreds digit</div> <div>Tens digit</div> <div>Units digit</div> <div>0: The output parameters of this channel are by default associated with Output Parameter Group 1. For example, setting On03~0 indicates that the output parameters of Channel 3 (CH03) use OPL1, OPH1, OHE1, dHA1, dLA1, HYS1, ACT1, SH1, and SdL1. 1~4: Select the corresponding output parameter group. For example, setting On01~2 indicates that the output parameters of Channel 1 (CH01) correspond to OPL2, OPH2, OHE2, dHA2, dLA2, HYS2, ACT2, SH2, and SdL2.</div> <div>Reserved</div>
029FH~02FFH	0672~0767	Pn01~ Pn96 Output Channel PID Configuration Parameter Group and Measurement Channel Selection	Spare
			<div>Thousand digit</div> <div>Hundreds digit</div> <div>Tens digit</div> <div>Units digit</div> <div>0: The output parameters of this channel are by default associated with Output Parameter Group 1. For example, setting On03~0 indicates that the output parameters of Channel 3 (CH03) use OPL1, OPH1, OHE1, dHA1, dLA1, HYS1, ACT1, SH1, and SdL1. 1~4: Select the corresponding output parameter group. For example, setting On01~2 indicates that the output parameters of Channel 1 (CH01) correspond to OPL2, OPH2, OHE2, dHA2, dLA2, HYS2, ACT2, SH2, and SdL2.</div> <div>Reserved</div>
0768~0863	0768~0863	AT01~AT96 Output Channel Operating Mode	Setting to 0 indicates the execution of the APID, i.e., the PID control algorithm with AI functionality; Setting to 1 indicates At auto-tuning; Setting to 2 activates the ON/OFF control mode; Setting to 3 activates manual control mode; Setting to 4 indicates stopping the control and disabling the output.
0300H~035FH		AT01~AT96 Definition Description	
		Function	Description
	0	APID Control Mode	Indicate that the channel executes APID, which is the PID control algorithm with AI functionality.
	2	Bit Control Mode	The channel executes the ON/OFF bit control mode.
	3	Manual Output Mode	Switch the channel to manual mode, allowing the output size to be adjusted by modifying OPxx.
	4	Stop Control	The channel stops control and disables output.

0360H~03BFH	0864~0959	OP01~OP96 Output Channel Output Value	In automatic mode, this channel is read-only and represents the PID control output value (for ON/OFF control, 0 means off and 25650 means on). In manual mode, this channel is both readable and writable, and the written value can serve as the manual output control value. The value 25600 indicates 100% output.
03C0H~041FH	0960~1055	HA01~HA96 Multifunctional Parameter 1	Setting range: -9990~32000. This is the high limit alarm value. The user can use AFA.5 to select whether it corresponds to the measurement value of the input or output channel (when the hundreds and thousands digits of the Pn parameter are not 0, the measurement values of the input and output channels can differ). It can also be defined as the positive deviation alarm for the output channel.
0420H~047FH	1056~1151	LA01~LA96 Multifunctional Parameter 2	Setting range: -9990~32000. This is the low limit alarm value. The user can use AFA.5 to select whether it corresponds to the measurement value of the input or output channel. It can also be defined as the negative deviation alarm.
0480H~04DFH	1152~1247	SV1~SV96 PID Actual Setpoint	In the ordinary fixed-point temperature control mode, this is simply equal to SP1~SP96. Note that in modes with heating/cooling slope control or secondary control mode in cascade control, it is not equal to SP1~SP96. When the heating/cooling slope limit function is available, the start setpoint can be defined by writing this parameter. At the same time, by inputting data for multiple channels , synchronized heating and cooling curves for multiple channels can be achieved.
04E0H~05FFH	1248~1535	Alternate Address	Reserved for future version upgrades. Please do not use.
0600H~065FH	1536~1631	Channel 1~96 Measurement Value	Read only; if the measurement value needs to be transmitted from the host computer, the channel can be closed and the Sc parameter written to achieve this. The system will automatically refresh this parameter.
0660H~066FH	1632~1647	Channel 1~8 Measurement Values 32-bit Data	Read only; provide high-resolution 32-bit data (positive values only) for channels 1~8, suitable for situations requiring high-resolution display. This measurement value can be secondary filtered using FL32.
0680H~06AFH	1664~1711	Alarm Status, 48 Parameters	Each parameter contains the alarm status for two channels. The high byte corresponds to the odd-numbered channel, and the low byte corresponds to the even-numbered channel. BIT0 to BIT4 correspond to the following alarms: Input error, HA, LA, dHA, and dLA. When the alarm lock function is enabled, this parameter can be written to unlock.
0680H~06AFH	Alarm Status Bits		Description (x or xx represents the channel number)
	Even channels e.g. CH02	Bit0	0: Sensor input signal is normal 1: Sensor input error or input signal exceeds the range oral
		Bit1	0: Input signal does not exceed the set upper limit HAxx value 1: Input signal exceeds the set upper limit HAxx value, triggering HA alarm
		Bit2	0: Input signal does not exceed the set lower limit LAxx value 1: Input signal exceeds the set lower limit LAxx value, triggering LA alarm
		Bit3	0: Input signal does not exceed the set upper limit deviation dHALx value 1: Input signal exceeds the set upper limit deviation dHAx value, triggering dHA alarm
		Bit4	0: Input signal does not exceed the set lower limit deviation dLAX value 1: Input signal exceeds the set lower deviation dLAX value, triggering dLA alarm
		Bit5~bit7	Spare
	O d d Numbered Channels e.g. CH01	Bit8	0: Sensor input signal is normal 1: Sensor input error or input signal exceeds the range oral
		Bit9	0: Input signal does not exceed the set upper limit HAxx value 1: Input signal exceeds the set upper limit HAxx value, triggering HA alarm
		Bit10	0: Input signal does not exceed the set lower limit LAxx value 1: Input signal exceeds the set lower limit LAxx value, triggering LA alarm
		Bit11	0: Input signal does not exceed the set upper limit deviation dHALx value 1: Input signal exceeds the set upper limit deviation dHAx value, triggering dHA alarm
		Bit12	0: Input signal does not exceed the set lower limit deviation dLAX value 1: Input signal exceeds the set lower deviation dLAX value, triggering dLA alarm
		Bit13~bit15	Spare
06C0H~06EFFH	1728~1775	Control Status, 48 Parameters	Read only; each parameter includes the control status of 2 channels. BIT0: 0 indicates auto-tuning state, 1 indicates non-auto-tuning state; BIT1: 0 indicates normal control, 1 indicates stop control state. Note: Do not write to this parameter. If need to change the related control status, write to the corresponding parameter. The system will automatically refresh this parameter.
06F0H~07FFH	Alarm Status Bits		Description (x or xx represents the channel number)
	Even channels e.g. CH02	Bit0	0: AT Auto-tuning in progress 1: Non-auto-tuning in progress
		Bit1	0: Normal control mode 1: Current channel is in stop control state (STOP mode)
		Bit2~bit7	Spare
	O d d Numbered Channels e.g. CH01	Bit8	0: AT Auto-tuning in progress 1: Non-auto-tuning in progress
		Bit9	0: Normal control mode 1: Current channel is in stop control state (STOP mode)
		Bit10~bit15	Spare
06F0H~07FFH	1776~2047	Alternate Address	Reserved for future version upgrades. Please do not use.
0800~0803H	2048~2051	InP1~4; Input Specification Definition	The 60xx series does not have its own input, so there is no need to set the input specification INP.
0804H~0807H	2052~2055	SCL1~4 Linear Input Calibration Lower Limit Value	Define the lower limit of the linear input scale, with units the same as the measured value.
0808H~080BH	2056~2059	SCH1~4 Scale upper limit value	Define the upper limit of the linear input scale, with units the same as the measured value.
080CH~080FH	2060~2063	FIL1~4 Digital Filtering	Define the intensity of digital filtering for the input. A setting of 0 means no filtering, 1 represents median value filtering, and values greater than 2 represent integration filtering. The unit is the sampling period.
0810H~0813H	2064~2067	dHA1~4 Alarm Parameters	The default is positive deviation alarm, but it can also be defined as a high limit alarm. This is one of the output group parameters. The output parameter group can either select the same numbered parameter group as the input or choose a different parameter group. The instrument has a total of 4 sets of output parameters.
0814H~0817H	2068~2071	dLA1~4 Alarm Parameters	The default is negative deviation alarm, but it can also be defined as a low limit alarm.



0818H~081BH	2072~2075	AAF1~4 Alarm Function Selection	AAF0~AAF.4 select whether the input fault, HA alarm, LA alarm, dHA, and dLA alarms will be automatically reset or not. If set to 1, the alarm will not be automatically reset, and the customer needs to send a write command to clear the corresponding alarm status register to release the alarm action.
	AAF Detailed Explanation		Description
	Bit0		0: The alarm status automatically resets after the input signal error is cleared. 1: The alarm status does not automatically reset after the input signal error is cleared. To manually reset, write 0 to the corresponding bit of the alarm status parameter for the corresponding channel. For odd-numbered channels, write bit8=0 in the alarm status; for even-numbered channels, write bit0=0.
	Bit1		0: The alarm status automatically resets after the HA alarm is cleared. 1: The alarm status does not automatically reset after the HA alarm is cleared. To manually reset, write 0 to the corresponding bit of the alarm status parameter for the corresponding channel. For odd-numbered channels, write bit9=0 in the alarm status; for even-numbered channels, write bit1=0.
	Bit2		0: The alarm status automatically resets after the LA alarm is cleared. 1: The alarm status does not automatically reset after the LA alarm is cleared. To manually clear the alarm, write 0 to the corresponding bit in the alarm status parameter for the respective channel. For odd-numbered channels, write bit10=0 in the alarm status; for even-numbered channels, write bit2=0.
	Bit3		0: The alarm status automatically resets after the dHA alarm is cleared. 1: The alarm status does not automatically reset after the dHA alarm is cleared. To manually clear the alarm, write 0 to the corresponding bit in the alarm status parameter for the respective channel. For odd-numbered channels, write bit11=0 in the alarm status; for even-numbered channels, write bit3=0.
	Bit4		0: The alarm status automatically resets after the dLA alarm is cleared. 1: The alarm status does not automatically reset after the dLA alarm is cleared. To manually clear the alarm, write 0 to the corresponding bit in the alarm status parameter for the respective channel. For odd-numbered channels, write bit10=0 in the alarm status; for even-numbered channels, write bit4=0.
Bit5~bit7		Spare	
081CH~081FH	2076~2079	HYS1~4 Hysteresis	The unit is the same as the measurement value. It is used as the hysteresis for alarms, ON/OFF control, and PID auto-tuning. However, auto-tuning can also use EHYS as the hysteresis by selecting it in Act.1.
0820H~0823H	2080~2083	OPL1~4 Output Low Limit	Setting range 0~100, default as output lower limit. It can also be defined as the output value in the event of input faults/overload.
0824H~0827H	2084~2087	OPH1~4 Output High Limit	Setting range: 0~105, used as the output upper limit.
0828H~082BH	2088~2091	OHE1~4 Segmented Power Limit Setting	OPH valid range, with the same unit as the measurement value. This is used to implement the segmented output limit function. When the measurement value is less than OHEF, the output is limited by OPH. When the measurement value exceeds OHEF, the output is not limited, i.e., it is 100%.
082CH~082FH	2092~2095	Act1~4 Control Function Selection	Act.0: Set to 0 for reverse action (heating), or 1 for direct action (cooling). Act.1: Set to 0 for using the HYS value of this parameter group as the hysteresis for self-tuning and ON/OFF control; set to 1 to use the global parameter EHYS as the hysteresis. Act.2: Set to 0 to force the output to 0 when an input fault occurs on this channel; set to 1 to force the output to OPL when an input fault occurs. Act.3: Set to 0 to define the output lower limit as OPL; set to 1 to fix the output lower limit at 0. Act.4: Set to 1 to force the output to the input fault state when a HA alarm occurs.
	ACT Detailed Explanation		Description
	Bit0		0: Reverse action mode (heating control) 1: Direct action mode (cooling control).
	Bit1		0: The At auto-tuning and (ON/OFF) bit control use the HYS value of this parameter group as the hysteresis. For example, if On01 = 2, then the hysteresis value for channel 2 will use HYS2. 1: The At auto-tuning and (ON/OFF) bit control use the global parameter EHYS as the hysteresis
	Bit2		0: When an input fault occurs on this channel, the output will be forced to 0 1: When an input fault occurs, the output will be forced to OPL
	Bit3		0: When an input fault occurs, the output will be forced to OPL 1: The output lower limit will be fixed at 0
	Bit4		0: The output will not be affected during the HA alarm 1: During the HA alarm, the output will also be forced to the same state as the input fault condition.
Bit5~bit7		Spare	
0830H~0833H	2096~2099	Srh1~4 Heating Slope Limit Value	Indicate the heating rate in degrees per minute. A value of 0 means no limit. When the SP value changes, the rate of change will be limited. Upon initial power-up or when control is started, the current measured value PV will be automatically set as the initial setpoint value. Additionally, if set AFC.3=1, any modification to the setpoint value SPXX will also automatically use the current measured value PV as the initial setpoint. Note this function does not apply to secondary control channels in cascade control mode. Note that the control cycle CTI value should be divisible by 60.0, such as 0.5, 0.8, 1.0, 1.2, 1.5, 2.0 seconds, etc. If other values are set, such as 0.9 or 1.1 seconds, there will be calculation errors in the heating slope value.
0834H~0837H	2100~2103	SrL1~4 Cooling Slope Limit Value	Indicate the cooling rate in degrees per minute. A value of 0 means no limit. The usage is the same as the Srh parameter.
0838H~083FH	2104~2111	Alternate address, please do not use	
0840H	2112	Addr Communication Address	Define the communication address of this device, with a range of 0~88.
0841H	2113	bAud Communication Baud Rate	Define the baud rate, the unit is 0.1K, setting range: 4.8K~115.2K.
0842H	2114	Adn	This version does not currently support this function.
0843H	2115	ACH Extended Input Loop Count	If the communication input interface of the device's expansion module fails to receive sufficient measurement values from the input modules defined by ACH, a corresponding input fault alarm signal will be triggered. If the actual input exceeds the set value, it is meaningless. This parameter is only used to define the communication input alarm prompt range and does not disable the measurement channel. To disable the measurement channel, the In parameter should be set.
0844H	2116	Ctn Control Loop Count	Indicate the number of control loops enabled. Each control loop occupies 10ms of processing time. If set to 96, the actual control cycle will be at least 0.96 seconds.
0845H	2117	Srun Run/ Stop Selection	Normally, the instrument operates in automatic control mode, but each channel can independently set the At parameter to turn off. If Srun is set to 9655, all PID channels will stop control output, and one command shutdown can be realized. If Srun is set to 15, the control mode remains active; however, when the power is turned off and then back on, the system will automatically enter the 9655 global stop state.


0846H	2118	CTI	Define the control cycle, with a range of 0.1~5.0 seconds. 0.1 is the system's minimum achievable cycle. For example, if the total number of control loops Ctn=16, the actual execution control cycle will be 0.16 seconds. The minimum control cycle for this version cannot be less than 0.1 seconds.
0847H	2119	ALAL Alarm Common Output Configuration (requires external alarm module expansion)	ALAL.0~4 define whether input fault, HA alarm, LA alarm, dHA, and dLA alarms will be output as a common alarm. Set to 0 for no output; set to 1 for output. Any alarm will trigger the global common alarm output AL0 action. The global common alarm output requires the alarm output terminal to be installed on the host.
0848H	2120	ALCH Alarm Independent Output Range Configuration (requires external alarm module expansion)	Define the start and end numbers of the independent alarm output channels for expansion. Although up to 5*97 alarm signals can be generated, note that the maximum number of extended alarm output channels is 256. For instance, if each channel requires 4 independent alarms, the difference between the output channel and number and the output channel start number should not exceed 64.
0849H	2121	ALbt Alarm Independent Output Configuration	ALbt.0~4 define whether input fault (including over-range, open circuit, communication disconnection, etc.), HA alarm, LA alarm, dHA, and dLA alarms are output. Set to 0 for no output; set to 1 for output. For example, if ALAL = 7, ALbt = 3, and ALCH = 16, the extended alarm output module will output 3 common alarms and 32 independent alarm signals. The output terminal numbers 1~3 will correspond to the common input alarm, high limit alarm, and low limit alarm; terminals 4~7 will sequentially correspond to channel 1 input error alarm, channel 1 HA alarm, channel 2 input error alarm, channel 2 HA alarm, and so on. For another example, if ALAL = 0, ALbt = 31, and ALCH = 616, the system will output 55 alarm signals, with 5 alarms for each of channels 6~16.
084AH	2122	AFA Functional Parameters Configuration A	AFA.0: Set to 0 for HA as the default high limit alarm, or 1 for positive deviation alarm. AFA.1: Set to 0 for LA as the default lower limit alarm, or 1 for negative deviation alarm. AFA.2: Set to 0 for dHA as the default positive deviation alarm, or 1 for high limit alarm. AFA.3: Set to 0 for dLA as the default negative deviation alarm, or 1 for low limit alarm. AFA.4: Set to 0 for LA as the default low limit alarm, or 1 for high limit alarm (this adds an additional high limit alarm). AFA.5: Set to 0 for HA and LA alarms to correspond to input channels, or 1 for HA and LA alarms to correspond to output channels. (Note: do not use HA and LA as deviation alarms in this mode) AFA.6: Set to 0 for AL1 to be defined according to ALAL, or 1 for AL1 to be a global alarm AFA.7: Set to 0 for AL2 to be defined according to ALAL, or 1 for AL2 to be a global alarm
084BH	2123	AFB Function Parameter Configuration B	AFB.0 = 0: No multi-group PID functionality. AFB.0 = 1: Multi-group PID functionality is enabled. In this mode, there are 5 preset PID groups with automatic switching functionality. At this time, the maximum number of effective independent PID control channels is 16. The instrument divides the SV and PID parameter groups into 5*16 groups, where groups 1~16 correspond to the PID parameters currently used by channels 1~16. The subsequent 80 PID groups are arranged in order for each channel to use 5 groups. This means that each channel can preset up to 5 PID groups, which will automatically switch based on the current SF value. For example: If the setpoint SP1 is less than or equal to SP17, then P1, I1, and d1 will automatically be set to P17, I17, and d17. If SP1 is greater than SP17 but less than SP18, then P1, I1, and d1 will automatically be set to P18, I18, and d18. If SP1 is greater than SP18 but less than SP19, then P1, I1, and d1 will automatically be set to P19, I19, and d19. If SP1 is greater than all 5 preset SP values for switching, the PID parameters will remain unchanged. Similarly, channel 2 is associated with the PID group of channel 22~26, and so on.
084CH	2124	AFC Function Parameter Configuration C	AFC.0: Select communication parity bit. Set to 0 for no parity, or 1 for even parity. AFC.1=0: Choose linear output as 4~20mA or 2~10V; AFC.1=1: Choose current output as 0~20mA or 0~10V. AFC.2=0: No sensor backup function; AFC.2=1: Sensor backup function enabled. AFC.3=0: When using slope control, changes in the setpoint do not trigger the measurement value startup (PV START) function; AFC.3=1: When using slope control, changes in the setpoint trigger the measurement value startup function. Note that when using this function, the maximum number of control channels should not exceed 4. AFC.4=0: ADC converter provides better resistance to interference from a 50Hz power grid; AFC.4=1: ADC converter provides better resistance to interference from a 60Hz power grid. This setting is only applicable for countries using a 60Hz power grid. AFC.5=0: 0851H address master host status BIT0~BIT7 port status mode, where 1 indicates an output action and 0 indicates no action; AFC.5=1: 0851H address master host status BIT0~BIT7 port 0 indicates an action, and 1 indicates no action. AFC.6=0: the transmitter output scale is defined by the corresponding SCL and SCH; AFC.6=1: the transmitter output scale is defined by the corresponding SPL and SPH. AFC.7=0: When an external expansion module, such as YL-1016, is connected, output values are transmitted; AFC.7=1: When an external host is connected, PV measurement values are transmitted.
084DH	2125	Nonc	Nonc.0~5: Define the output as normally open (NO) or normally closed (NC) for input fault, HA alarm, LA alarm, dHA alarm, dLA alarm, and common alarm, respectively. 0: Normally open (closes when an alarm occurs). 1: Normally closed. Note that if the system is powered off, the relay is disconnected regardless of the settings
084EH	2126	EAF host sampling parameter configuration; note that this is only valid for the host's sampling rate. The sampling rate of the extended input module is configured by the extension module itself.	EAF=0: The main input refresh rate is automatically selected based on the CTI control cycle parameter. For thermocouples and voltage/current inputs, the fastest rate is 20ms; for RTD, it is 60ms. EAF=1: Fixed refresh rate of 20ms for each channel, with RTD inputs at 60ms. EAFAB=2: Fixed refresh rate of approximately 40ms, with RTD inputs at 120ms. EAFAB=3: Fixed refresh rate of approximately 80ms, with RTD inputs at 240ms.
084FH	2127	EHYS Additional Hysteresis	If a different hysteresis value is required for auto-tuning and ON/OFF control compared to the HYS alarm hysteresis, EHYS can be selected as the hysteresis value for auto-tuning and ON/OFF control through Act.1.
0850H	2128	dPt	The data range is 0~3, set the display decimal point position of the host operation panel. This setting is only for the convenience of displaying values on the basic operation panel and does not affect the data read by the host computer, the host computer program can handle the decimal point display by itself.
0851H	2129	Host Status	Read only, BIT0~5 indicates O1~O6 of the host computer, BIT11 corresponds to AL1, BIT12 corresponds to AL2 (For 8X88, BIT0~7 represent the status of the host's O1~O8, corresponding to 8 IO port statuses, respectively). 1 indicates output (can be defined by AFC.5). BIT8 is set to 1 to indicate a system fault, such as a memory data error, while BIT9 is set to 1 to signal the presence of a global alarm.
0852H	2130	Loc Parameter Locking	When Loc.5 is set to 0, all parameters can be written; when set to 1, writing parameters in the range of 0800H~08FFH is not allowed. Loc.6, when set to 0 and 1, respectively, indicates whether single-byte write commands are allowed or not. Loc.7, when set to 0 and 1, respectively, indicates whether multi-byte write commands are allowed or not. When writing is not allowed, the instrument will still return the command but will not actually modify the parameter.

0853H	2131	Instrument Model Characteristic Code	Read-only, indicate the instrument model.
0854H	2132	Machine Number High Bits	Read-only, indicate the high 4 digits of the machine number.
0855H	2133	Machine Number Low Bits	Read-only, indicate the lower 4 digits of the machine number.
0856H	2134	OPCH Output Start Channel	OPCH Local output start channel of this device: When set to 1, output 1 corresponds to channel 1. For example, if set to 5, output 1 corresponds to the output value of channel 5, OP5. This function is used in cases where channels 1~4 are used for calculation only and do not directly output.
0857H	2135	FL32 High-Resolution Measurement Filtering Constant	The unit is the sampling period, with a setting range of 0~999. This parameter applies high-resolution secondary filtering to the 32-bit data of 8 channels, improving the stability of the displayed data. This filtering does not apply to PID regulation. Typically, the workpiece being heated has a larger mass-to-volume ratio than the temperature sensor, so its thermal conductivity is slower than the sensor's response. By properly setting this filtering parameter, a more accurate representation of the actual internal temperature of the heated workpiece can be obtained.
0858H	2136	AlF1 Heating and Overshoot Adjustment Parameter 1	Used by the manufacturer's debugging personnel
0859H	2137	AlF2 Heating and Overshoot Adjustment Parameter 2	Used by the manufacturer's debugging personnel
085AH	2138	AlF3 Heating and Overshoot Adjustment Parameter 3	Used by the manufacturer's debugging personnel
085BH	2139	dIFa	Used by the manufacturer's debugging personnel
085CH	2140	SPSr	Used by the manufacturer's debugging personnel
		OPSn	Used by the manufacturer's debugging personnel
085DH	2141	AtFn	The At auto-tuning style parameter has a default factory setting of 55. When the difference between the PV and SV register values exceeds 600, a fast tuning mode is used, which requires only one heating cycle to determine the PID parameters (when INP = 13/17/18/22/35/36, the difference is 2000). When the difference is smaller, conventional auto-tuning is performed, requiring two heating and cooling cycles to complete. In the old version, the cutoff point was at SV, while in the new version, the cutoff point is slightly earlier. The tens digit of the AtFn parameter is used to adjust the size of the auto-tuning proportional band, with a range from 0~9. A larger number results in a larger proportional band for the auto-tuning. The ones digit is used to adjust the rate of heating, either faster or smoother. It will adjust the PID parameters accordingly, larger numbers are suitable for smoother heating, while smaller numbers result in more aggressive heating. If set to 10XX, where the thousands digit is 1, conventional auto-tuning will be forced.
0861H~088FH	2145~2191	Spare	
0898H~08FBH	2200~2099	Input Nonlinearity Calibration Table Data, etc.	Include input calibration curves, high-temperature furnace output limiting curves, etc., totaling 100 data.
0900H~	2305~	Temporarily Disable Read/Write	

- Description:
- When developing the host computer software, ensure that the instrument responds to each valid command within 0~5mS (Note: this excludes data transmission time and the interval required by the MODBUS protocol, which should be calculated based on different baud rates and data lengths). The host computer must wait for the instrument to return data before sending a new command; otherwise, errors may occur. If the instrument does not respond within the maximum response time, the potential reasons could include invalid commands, incorrect instrument or parameter addresses, communication line faults, the instrument being powered off, or mismatched communication addresses. In such cases, the host computer should resend the command or skip that instrument's address.
  - Except for input errors, all other alarms on the instrument are generated based on the selected input values of the control channels. Typically, the input and control channel numbers are the same, but if they are different, e.g., if control channel 2 selects input channel 1 for the measurement value PV input, then the alarms for channel 2 will be based on the absolute value and control deviation of input channel 1, and will not relate to input channel 2. In particular, if two control channels select the same input channel for the measurement value, that channel's measurement value can have up to 8 related alarm settings at most. In addition, for input channels that are not selected, they should typically be disabled. Otherwise, the measurement behavior of that channel may affect the input error flags of the selected input channel associated with the output channel of the same number.
  - If any alarm condition is met, an additional global public alarm signal will be triggered. This alarm does not come from the extended alarm module but instead illuminates the host's own alarm indicator. It can be read through BIT9 of the 0851H. If the host has an optional alarm output module, this alarm can be output from the host.
  - The instrument will impose write range restrictions on parameter values in the address range 0800H~088FH. If an attempt is made to write data outside of this range, the error will still be executed, but the system will limit the range to prevent system malfunctions caused by writing out-of-range data.
  - Alarm Explanation  
How to set up and drive AL1 and AL2, with related alarm parameters:  
HA01~HA96: These are set as high limit absolute value alarms by default, but can be reconfigured as high deviation alarms.  
LA01~LA96: These are set as low limit absolute value alarms by default, but can be reconfigured as low deviation alarms.  
dHA1~dHA4: These are set as high deviation alarms by default, but can be reconfigured as high absolute value alarms.  
dLA1~dLA4: These are set as low deviation alarms by default, but can be reconfigured as low absolute value alarms.  
AAF1~4: Alarm function selection, which determines whether the output and status are reset after the alarm is automatically cleared.  
HYS1-4: Hysteresis, the difference by which the alarm is cleared.  
ALAL: Define whether each alarm will output  
ALCH: Used when connecting an external alarm output module  
ALbt: Also used when connecting an external alarm output module

#### 4. Wiring Method

##### 6016D92 Wiring Diagram




The O1~16 indicator lights are used to indicate whether there is output on each of the 16 channels. The C1 indicates 485 communication, the C2 indicates 422 communication ( with PV transmission input), the AL indicates a global alarm, and the A1 represents AL1, A2 represents AL2.

The COM output terminal is used to connect the negative of an external switch power supply. Terminals O1~O16 connect to the negative of the rear solid-state or relay outputs, with the positive of the rear solid-state or relay connected to the positive of the switch power supply. Terminals A and B are used to connect to host computers A and B for 485 communication.

(OUT3 is a spare terminal used for other modules and is generally not used.)

##### 6032D92 Wiring Diagram



The O1~32 indicator lights are used to indicate whether there is output on each of the 32 channels. Light 33 indicates 485 communication. Light 34 indicates 422 communication (with PV transmission input). Light 35 indicates a global alarm. Light 36 indicates AL1.

The -12V output terminal is used to connect the negative of an external switch power supply. Terminals O1~O32 connect to the negative of the rear solid-state or relay outputs, with the positive of the rear solid-state or relay connected to the positive of the switch power supply. Terminals A and B are used to connect to host computers A and B for 485 communication.

(OUT3 is a spare terminal used for other modules and is generally not used.)

#### 5. Wiring Method

AI-6608D92 Input Wiring

Indicator lights O1-O8 are used to indicate whether there is a fault in the corresponding input. C1 indicates 485 communication; C2 indicates 422 communication (PV transmission input). A1 represents a global alarm; A2 corresponds to the AL1 alarm output. The input wiring is illustrated using Channel 1 as an example: Connect a pair of wires with low resistance between RTD1 and IN+; connect another pair between IN1- and COM1. A1 and A2 are used for alarm output. When equipped with the L21 module, the output is a dry contact, but the voltage in series must not exceed 28V. When equipped with the G module, A1 serves as the positive terminal and A2 as the negative terminal, providing a 12V, 30mA output signal. 24V+ and 24V- are the power supply terminals on the front. The instrument can also be powered via the base power terminals.

This product is restriction of use in the industrial environment.

ADDRESS: No.6 Longku East Road, Xiang'an District, Xiamen, Fujian, 361101, China

